

§ 166.200

33 CFR Ch. I (7-1-99 Edition)

Subpart B—Designations of Fairways and Fairway Anchorages

§ 166.200 Shipping safety fairways and anchorage areas, Gulf of Mexico.

(a) *Purpose.* Fairways and anchorage areas as described in this section are established to control the erection of structures therein to provide safe approaches through oil fields in the Gulf of Mexico to entrances to the major ports along the Gulf Coast.

(b) *Special Conditions for Fairways in the Gulf of Mexico.* Temporary anchors and attendant cables or chains attached to floating or semisubmersible drilling rigs outside a fairway may be placed within a fairway described in this section for the Gulf of Mexico, provide the following conditions are met:

(1) Anchors installed within fairways to stabilize semisubmersible drilling rigs shall be allowed to remain 120 days. This period may be extended by the Army Corps of Engineers, as provided by § 209.135(b).

(2) Drilling rigs must be outside of any fairway boundary to whatever distance is necessary to ensure that the minimum depth of water over an anchor line within a fairway is 125 feet.

(3) No anchor buoys or floats or related rigging will be allowed on the surface of the water or to a depth of at least 125 feet from the surface, within a fairway.

(4) Aids to Navigation or danger markings must be installed as required by 33 CFR Subchapter C.

(c) *Special Conditions for Fairway Anchorages in the Gulf of Mexico.* Structures may be placed within an area designated as a fairway anchorage, but the number of structures will be limited by spacing as follows:

(1) The center of a structure to be erected shall not be less than two (2) nautical miles from the center of any existing structure.

(2) In a drilling or production complex, associated structures connected by walkways shall be considered one structure for purposes of spacing, and shall be as close together as practicable having due consideration for the safety factors involved.

(3) A vessel fixed in place by moorings and used in conjunction with the associated structures of a drilling or

production complex, shall be considered an attendant vessel and the extent of the complex shall include the vessel and its moorings.

(4) When a drilling or production complex extends more than five hundred (500) yards from the center, a new structure shall not be erected closer than two (2) nautical miles from the outer limit of the complex.

(5) An underwater completion installation in an anchorage area shall be considered a structure and shall be marked with a lighted buoy approved by the United States Coast Guard under § 66.01.

(d) *Designated Areas.*

(1) *Brazos Santiago Pass Safety Fairway.* The areas between rhumb lines joining points at:

Latitude	Longitude
26°03' 27"	97°08' 36"
26°02' 57"	97°07' 11"
26°02' 06"	96°57' 24"
25°58' 54"	96°19' 00"

and rhumb lines joining points at:

Latitude	Longitude
26°04' 27"	97°08' 36"
26°04' 58"	97°07' 07"
26°04' 12"	96°59' 30"
26°04' 00"	96°57' 24"
26°00' 54"	96°19' 00"

(2) *Brazos Santiago Pass Anchorage Areas.* The areas enclosed by rhumb lines joining points at:

Latitude	Longitude
26°02' 57"	97°07' 11"
26°02' 06"	96°57' 24"
25°58' 54"	96°57' 24"
25°58' 54"	97°07' 18"
26°02' 57"	97°07' 11"

and rhumb lines joining points at:

Latitude	Longitude
26°04' 58"	97°07' 07"
26°09' 00"	97°07' 00"
26°09' 00"	96°59' 30"
26°04' 12"	96°59' 30"
26°04' 58"	97°07' 07"

(3) *Port Mansfield Safety Fairway.* The area between a rhumb line joining points at:

Latitude	Longitude
26°33'39"	97°16'04"
26°33'43"	97°14'38"

and rhumb lines joining points at:

Coast Guard, DOT

§ 166.200

Latitude	Longitude
26°34'04"	97°16'05"
26°34'40"	97°15'47"
26°34'43"	97°14'40"

(4) *Aransas Pass Safety Fairway.* The area between rhumb lines joining points at:

Latitude	Longitude
27°49' 21"	97°02' 08"
27°48' 11"	97°01' 06"
27°46' 26"	96°57' 40"
27°45' 14"	96°55' 26"
27°44' 09"	96°53' 25"
27°42' 47"	96°51' 39"
27°39' 24"	96°48' 26"
27°21' 59"	96°11' 42"

and rhumb lines joining points at:

Latitude	Longitude
27°50' 15"	97°01' 32"
27°49' 54"	96°59' 56"
27°45' 22"	96°51' 19"
27°44' 35"	96°48' 31"
27°43' 49"	96°45' 47"
27°35' 17"	96°27' 46"
27°33' 33"	96°24' 06"
27°25' 53"	96°07' 56"

separated by areas enclosed by rhumb lines joining points at:

Latitude	Longitude
27°41' 10"	96°47' 23"
27°34' 50"	96°34' 01"
27°34' 59"	96°31' 56"
27°42' 03"	96°46' 51"
27°41' 10"	96°47' 23"

and rhumb lines joining points at:

Latitude	Longitude
27°33' 06"	96°30' 21"
27°23' 33"	96°10' 12"
27°24' 19"	96°09' 26"
27°33' 15"	96°28' 16"
27°33' 06"	96°30' 21"

(5) *Aransas Pass Anchorage Areas.* The areas enclosed by rhumb lines joining points at:

Latitude	Longitude
27°49' 54"	96°59' 56"
27°45' 22"	96°51' 19"
27°51' 46"	96°40' 12"
27°53' 36"	96°56' 30"
27°49' 54"	96°59' 56"

and rhumb lines joining points at:

Latitude	Longitude
27°45' 14"	96°55' 26"
27°43' 00"	96°55' 27"
27°44' 09"	96°53' 25"
27°45' 14"	96°55' 26"

(6) *Matagorda Entrance Safety Fairway.* The areas between rhumb lines joining points at:

Latitude	Longitude
28°24'50"	96°19'38"
28°22'16"	96°17'40"
28°14'48"	96°09'42"
28°11'24"	96°06'06"
28°10'06"	96°04'42"
27°38'02"	95°49'39"

with rhumb lines joining points at:

Latitude	Longitude
28°25'31"	96°18'48"
28°23'38"	96°16'00"
28°16'12"	96°08'06"
28°12'30"	96°04'12"
28°11'13"	96°02'46"
27°38'12"	95°47'19"

(7) *Matagorda Entrance Anchorage Areas.* The areas enclosed by rhumb lines joining points at:

Latitude	Longitude
28°22'16"	96°17'40"
28°14'48"	96°09'42"
28°12'42"	96°12'12"
28°20'12"	96°20'12"
28°22'16"	96°17'40"

and rhumb lines joining points at:

Latitude	Longitude
28°23'38"	96°16'00"
28°25'36"	96°13'36"
28°18'12"	96°05'36"
28°16'12"	96°08'06"
28°23'38"	96°16'00"

(8) *Freeport Harbor Safety Fairway.* The area between rhumb lines joining points at:

Latitude	Longitude
28°55' 19"	95°17' 46"
28°52' 58"	95°16' 06"
28°44' 52"	95°07' 43"
28°43' 32"	95°06' 18"
28°04' 48"	94°26' 12"

and rhumb lines joining points at:

Latitude	Longitude
28°55' 59"	95°16' 55"
28°54' 05"	95°14' 10"
28°45' 58"	95°05' 48"
28°44' 39"	95°04' 22"
28°07' 46"	94°26' 12"

(9) *Freeport Harbor Anchorage Areas.* The areas enclosed by rhumb lines joining points at:

Latitude	Longitude
28°52' 58"	95°16' 06"
28°44' 52"	95°07' 43"

§ 166.200

Latitude	Longitude
28°42' 24"	95°12' 00"
28°51' 30"	95°18' 42"
28°52' 58"	95°16' 06"

and rhumb lines joining points at:

Latitude	Longitude
28°54' 05"	95°14' 10"
28°56' 54"	95°09' 18"
28°47' 42"	95°02' 42"
28°45' 58"	95°05' 48"
28°54' 05"	95°14' 10"

(10) *Galveston Entrance Safety Fairways.* The areas between rhumb lines joining points at:

Latitude	Longitude
27°44' 03"	94°26' 12"
28°04' 48"	94°26' 12"
28°07' 46"	94°26' 12"
29°06' 24"	94°26' 12"
29°07' 42"	94°27' 48"
29°18' 10"	94°39' 16"
29°19' 39"	94°41' 33"
29°20' 44"	94°40' 44"
29°19' 23"	94°37' 08"
29°10' 30"	94°22' 54"
29°10' 17"	94°22' 30"
29°09' 06"	94°20' 36"
28°17' 17"	92°57' 59"

and rhumb lines joining points at:

Latitude	Longitude
27°44' 13"	94°23' 57"
29°06' 24"	94°23' 55"
29°07' 41"	94°22' 23"
28°11' 57"	92°53' 25"

(11) *Galveston Entrance Anchorage Areas.* The areas enclosed by rhumb lines joining points at:

Latitude	Longitude
29°18' 10"	94°39' 16"
29°08' 04"	94°28' 12"
29°03' 13"	94°36' 48"
29°14' 48"	94°45' 12"
29°18' 10"	94°39' 16"

and rhumb lines joining points at:

Latitude	Longitude
29°19' 23"	94°37' 08"
29°22' 18"	94°32' 00"
29°14' 23"	94°25' 53"
29°13' 24"	94°27' 33"
29°19' 23"	94°37' 08"

(12) *Sabine Pass Safety Fairway.* The areas between rhumb lines joining points at:

Latitude	Longitude
29°38' 25"	93°50' 02"
29°35' 19"	93°49' 10"
29°33' 00"	93°46' 26"

33 CFR Ch. I (7-1-99 Edition)

Latitude	Longitude
29°32' 03"	93°46' 44"
29°30' 39"	93°43' 41"
29°28' 30"	93°41' 09"
29°07' 28"	93°41' 08"
28°17' 17"	92°57' 59"
28°11' 57"	92°53' 25"
27°51' 58"	92°36' 20"

and rhumb lines joining points at:

Latitude	Longitude
29°38' 48"	93°48' 59"
29°37' 32"	93°48' 02"
29°36' 28"	93°47' 14"
29°32' 52"	93°43' 00"
29°31' 13"	93°41' 04"
29°29' 20"	93°38' 51"
29°08' 08"	93°38' 52"
28°39' 02"	93°13' 39"
28°36' 15"	93°11' 15"
27°52' 09"	92°33' 40"

(13) *Sabine Pass Anchorage Areas—(i) Sabine Pass Inshore Anchorage Area.* The area enclosed by rhumb lines joining points at:

Latitude	Longitude
29°37'32" N.	93°48'02" W.
29°37'32" N.	93°21'25" W.
29°32'52" N.	93°43'00" W.
29°36'28" N.	93°47'14" W.

(ii) *Sabine Bank Offshore (North) Anchorage Area.* The area enclosed by rhumb lines joining points at:

Latitude	Longitude
29°26'06" N.	93°43'00" W.
29°26'06" N.	93°41'08" W.
29°24'06" N.	93°41'08" W.
29°24'06" N.	93°43'00" W.

(iii) *Sabine Bank Offshore (South) Anchorage Area.* The area enclosed by rhumb lines joining points at:

Latitude	Longitude
29°16'55" N.	93°43'00" W.
29°16'55" N.	93°41'08" W.
29°14'29" N.	93°41'08" W.
29°14'29" N.	93°43'00" W.

(14) *Coastwise Safety Fairways.* (i) *Brazos Santiago Pass to Aransas Pass.* The areas between rhumb lines joining points at:

Latitude	Longitude
26°04' 12"	96°59' 30"
26°09' 00"	96°59' 30"
27°46' 26"	96°57' 40"

and rhumb lines joining points at:

Latitude	Longitude
25°58' 54"	96°57' 24"

Coast Guard, DOT

§ 166.200

Latitude	Longitude
26°02' 06"	96°57' 24"
26°04' 00"	96°57' 24"
27°40' 36"	96°55' 30"
27°43' 00"	96°55' 27"
27°45' 14"	96°55' 26"

(ii) *Aransas Pass to Calcasieu Pass.* The areas between rhumb lines joining points at:

Latitude	Longitude
27°43'00"	94°55'27"
27°44'09"	96°53'25"
27°45'22"	96°51'19"
27°51'46"	96°40'12"
28°11'24"	96°06'06"
28°12'30"	96°04'12"
28°42'24"	95°12'00"
28°44'52"	95°07'43"
28°45'58"	95°05'48"
28°47'42"	95°02'42"
29°07'42"	94°27'48"
29°10'17"	94°22'30"
29°29'30"	93°58'24"
29°32'03"	93°46'44"
29°33'00"	93°46'26"
29°32'52"	93°43'00"
29°37'32"	93°21'25"

with rhumb lines joining points at:

Latitude	Longitude
27°40'36"	96°55'30"
27°42'47"	96°51'39"
27°44'35"	96°48'31"
28°10'06"	96°04'42"
28°11'13"	96°02'46"
28°43'32"	95°06'18"
28°44'39"	95°04'22"
29°06'24"	94°26'12"
29°06'24"	94°23'55"
29°07'41"	94°22'23"
29°09'06"	94°20'36"
29°27'40"	93°57'18"
29°30'39"	93°43'41"
29°31'13"	93°41'04"
29°33'56"	93°28'35"
29°32'57"	93°17'00"

(15) *Calcasieu Pass Safety Fairway.* The areas between rhumb lines joining points at:

Latitude	Longitude
29°45' 00"	93°20' 58"
29°40' 56"	93°20' 18"
29°38' 18"	93°20' 42"
29°37' 32"	93°21' 25"
29°32' 57"	93°17' 00"
29°31' 08"	93°14' 38"
28°39' 02"	93°13' 39"

and rhumb lines joining points at:

Latitude	Longitude
29°45' 05"	93°20' 03"
29°41' 12"	93°19' 37"
29°37' 30"	93°18' 15"
29°31' 16"	93°12' 16"
28°36' 15"	93°11' 15"

(16) *Calcasieu Pass Anchorage Areas—(i) Calcasieu Pass North Anchorage Area.* The area enclosed by rhumb lines joining points at:

Latitude	Longitude
29°41'12" N.	93°19'37" W.
29°41'12" N.	93°12'28" W.
29°31'16" N.	93°12'16" W.
29°37'30" N.	93°18'15" W.

(ii) *Calcasieu Pass South Anchorage Area.* The area enclosed by rhumb lines joining points at:

Latitude	Longitude
28°59'30" N.	93°16'30" W.
28°59'30" N.	93°14'00" W.
28°56'00" N.	93°14'00" W.
28°56'00" N.	93°16'30" W.

(17) *Lower Mud Lake Safety Fairway.* The area enclosed by rhumb lines joining points at:

Latitude	Longitude
29°43'24" N.	93°00'18" W.
29°42'00" N.	93°00'18" W.

and rhumb lines joining points at:

Latitude	Longitude
29°43'33" N.	93°00'48" W.
29°42'00" N.	93°00'48" W.

(18) *Freshwater Bayou Safety Fairway.* The area between lines joining points at:

Latitude	Longitude
29°31' 59"	92°18' 45"
29°31' 10"	92°18' 54"
29°31' 13"	92°19' 14"
29°27' 44"	92°19' 53"

and a line joining points at:

Latitude	Longitude
29°27' 34"	92°18' 45"
29°31' 03"	92°18' 06"
29°31' 06"	92°18' 26"
29°31' 55"	92°18' 17"

(19) *Southwest Pass Safety Fairway.* The area between lines joining points at:

Latitude	Longitude
29°34' 48"	92°03' 12"
29°30' 48"	92°07' 00"
29°23' 30"	92°08' 24"

and lines joining points at:

Latitude	Longitude
29°34' 24"	92°02' 24"
29°30' 24"	92°06' 12"

§ 166.200

Latitude	Longitude
29°23' 24"	92°07' 30"

(20) *Atchafalaya Pass Safety Fairway.* The area between a line joining points at:

Latitude	Longitude
29°22' 36"	91°23' 28"
29°14' 42"	91°30' 28"

and a line joining points at:

Latitude	Longitude
29°14' 05"	91°29' 34"
29°21' 59"	91°22' 34"

(21) *Bayou Grand Caillou Safety Fairway.* The area between a line joining points at:

Latitude	Longitude
29°10' 59"	90°57' 26"
29°05' 24"	90°58' 10"
29°01' 08"	91°00' 44"

and a line joining points at:

Latitude	Longitude
29°00' 40"	90°59' 43"
29°05' 06"	90°57' 03"
29°09' 46"	90°56' 27"

(22) *Cat Island Pass Safety Fairway.* The area between lines joining points at:

Latitude	Longitude
29°05' 57"	90°34' 32"
29°04' 56"	90°35' 09"
29°03' 14"	90°35' 10"
29°03' 14"	90°35' 17"
29°01' 24"	90°34' 55"

and lines joining points at:

Latitude	Longitude
29°06' 00"	90°34' 21"
29°05' 31"	90°34' 12"
29°03' 13"	90°34' 13"
29°03' 13"	90°34' 07"
29°01' 34"	90°33' 47"

(23) *Belle Pass Safety Fairway.* The area between a line joining points at:

Latitude	Longitude
29°05' 06"	90°14' 07"
29°02' 50"	90°14' 46"

and a line joining points at:

Latitude	Longitude
29°02' 56"	90°13' 48"
29°05' 06"	90°13' 10"

33 CFR Ch. I (7-1-99 Edition)

(24) *Barataria Pass Safety Fairway.* The area between a line joining points at:

Latitude	Longitude
29°16' 00"	89°57' 00"
29°14' 54"	89°55' 48"

and a line joining points at:

Latitude	Longitude
29°16' 30"	89°56' 06"
29°15' 18"	89°55' 00"

(25) *Grand Bayou Pass Safety Fairway.* The areas between a line joining points at:

Latitude	Longitude
29°17' 36"	89°41' 36"
29°16' 48"	89°42' 12"

and a line joining points at:

Latitude	Longitude
29°17' 18"	89°40' 36"
29°16' 18"	89°41' 18"

(26) *Empire to the Gulf Safety Fairway.* The area between a line joining points at:

Latitude	Longitude
29°15' 22"	89°36' 55"
29°13' 52"	89°37' 15"

and a line joining points at:

Latitude	Longitude
29°13' 24"	89°36' 11"
29°14' 54"	89°35' 51"

(27) *Gulf Safety Fairway. Aransas Pass Safety Fairway to Southwest Pass Safety Fairway.* The areas between rhumb lines joining points at:

Latitude	Longitude
27°33' 06"	96°30' 21"
27°33' 15"	96°28' 16"
27°33' 33"	96°24' 06"
28°00' 36"	90°08' 18"

and rhumb lines joining points at:

Latitude	Longitude
27°34' 50"	96°34' 01"
27°34' 59"	96°31' 56"
27°35' 17"	96°27' 46"
27°38' 02"	95°49' 39"
27°38' 12"	95°47' 19"
27°44' 03"	94°26' 12"
27°44' 13"	94°23' 57"
27°51' 58"	92°36' 20"
27°52' 09"	92°33' 40"
28°02' 32"	90°09' 28"

Coast Guard, DOT

§ 166.200

(28) *Southwest Pass (Mississippi River) Safety Fairway*—(i) *Southwest Pass (Mississippi River) to Gulf Safety Fairway*. The area enclosed by rhumb lines joining points at:

Latitude	Longitude
28°54'33" N.	89°26'07" W.
28°52'42" N.	89°27'06" W.
28°50'00" N.	89°27'06" W.
28°02'32" N.	90°09'28" W.

and rhumb lines joining points at:

28°54'18" N.	89°25'46" W.
28°53'30" N.	89°25'18" W.
28°53'30" N.	89°23'48" W.
28°50'40" N.	89°24'48" W.
28°48'48" N.	89°24'48" W.
28°47'24" N.	89°26'30" W.
28°00'36" N.	90°08'18" W.

(ii) *Southwest Pass (Mississippi River) to Sea Safety Fairway*. The area enclosed by rhumb lines joining points at:

Latitude	Longitude
28°54'33" N.	89°26'07" W.
28°52'42" N.	89°27'06" W.
28°50'00" N.	89°27'06" W.
28°47'24" N.	89°26'30" W.
28°36'28" N.	89°18'45" W.

and rhumb lines joining points at:

28°54'18" N.	89°25'46" W.
28°53'30" N.	89°25'18" W.
28°53'30" N.	89°23'48" W.
28°50'40" N.	89°24'48" W.
28°48'48" N.	89°24'48" W.
28°45'06" N.	89°22'12" W.
28°43'27" N.	89°21'01" W.
28°37'54" N.	89°17'06" W.

(iii) *Southwest Pass (Mississippi River) to South Pass (Mississippi River) Safety Fairway*. The areas between rhumb line joining points at:

Latitude	Longitude
28°45' 06"	89°22' 12"
28°55' 56"	89°03' 09"

and rhumb lines joining points at:

Latitude	Longitude
28°43' 27"	89°21' 01"
28°54' 55"	89°00' 44"

(29) *Southwest Pass (Mississippi River) Anchorage*. The area enclosed by rhumb lines joining points at:

Latitude	Longitude
28°53'30" N.	89°23'48" W.
28°53'30" N.	89°21'48" W.
28°55'06" N.	89°21'48" W.
28°55'06" N.	89°19'18" W.
28°52'41" N.	89°17'30" W.

Latitude	Longitude
28°50'40" N.	89°21'14" W.
28°50'40" N.	89°24'48" W.

(30) *South Pass (Mississippi River) Safety Fairway*. (i) *South Pass to Sea Safety Fairway*. The areas between rhumb lines joining points at:

Latitude	Longitude
28°59' 18"	89°08' 30"
28°58' 42"	89°07' 30"
28°58' 09"	89°08' 30"
28°55' 56"	89°03' 09"
28°54' 55"	89°00' 44"
28°54' 15"	88°59' 00"

and rhumb lines joining points at:

East jetty light	
28°59' 24"	89°08' 12"
29°00' 09"	89°07' 24"
29°00' 00"	89°07' 00"
28°57' 56"	89°02' 18"
28°57' 18"	89°00' 48"
28°56' 16"	88°58' 29"
28°55' 42"	88°57' 06"

(ii) *South Pass (Mississippi River) to Mississippi River-Gulf Outlet Channel Safety Fairway*. The areas between rhumb lines joining points at:

Latitude	Longitude
28°57' 18"	89°00' 48"
29°04' 18"	88°48' 31"
29°24' 35"	88°57' 17"

and rhumb lines joining points at:

Latitude	Longitude
28°56' 16"	88°58' 29"
29°03' 30"	88°45' 42"
29°23' 06"	88°54' 11"
29°26' 28"	88°55' 39"

(31) *South Pass (Mississippi River) Anchorage*. The areas within rhumb lines joining points at:

Latitude	Longitude
29°00' 00"	89°07' 00"
29°03' 36"	89°02' 18"
28°57' 56"	89°02' 18"

(32) *Mississippi River-Gulf Outlet Safety Fairway*. (i) The areas between rhumb lines joining points at:

Latitude	Longitude
29°42' 10"	89°25' 49"
29°29' 33"	89°07' 47"
29°27' 14"	89°03' 20"
29°24' 38"	89°00' 00"
29°24' 35"	88°57' 17"

§ 166.200

and rhumb lines joining points at:

Latitude	Longitude
29°42' 29"	89°25' 31"
29°29' 53"	89°07' 31"
29°27' 01"	89°01' 54"
29°26' 38"	88°58' 43"

(ii) *Mississippi River-Gulf Outlet Channel to Mobile Ship Channel Safety Fairway.* The areas within rhumb lines joining points at:

Latitude	Longitude
29°26' 38"	88°58' 43"
29°29' 57"	88°54' 48"
29°38' 59"	88°44' 04"
29°56' 43"	88°20' 50"
29°58' 03"	88°19' 05"
30°05' 29"	88°09' 19"

and rhumb lines joining points at:

Latitude	Longitude
29°26' 28"	88°55' 39"
29°27' 54"	88°53' 54"
29°37' 32"	88°42' 28"
29°55' 14"	88°19' 15"
29°56' 34"	88°17' 30"
30°03' 50"	88°08' 01"
30°05' 15"	88°06' 05"

(33) *Mississippi River-Gulf Outlet Anchorage.* (i) The areas within rhumb lines joining points at:

Latitude	Longitude
29°27' 01"	89°01' 54"
29°32' 12"	88°55' 42"
29°29' 57"	88°54' 48"
29°26' 38"	88°58' 43"

(ii) The areas within rhumb lines joining points at:

Latitude	Longitude
29°26' 28"	88°55' 39"
29°27' 54"	88°53' 54"
29°24' 33"	88°52' 27"
29°23' 06"	88°54' 11"

(34) *Gulfport Safety Fairway.* The areas between rhumb lines joining points at:

Latitude	Longitude
30°20' 54"	89°05' 36"
30°13' 56"	88°59' 42"
30°11' 09"	88°59' 56"
30°06' 45"	88°56' 24"
30°05' 42"	88°56' 24"

and rhumb lines joining points at:

Latitude	Longitude
30°21' 27"	89°04' 38"
30°14' 11"	88°58' 29"
30°11' 29"	88°58' 45"
30°07' 42"	88°55' 37"

33 CFR Ch. I (7-1-99 Edition)

(35) *Biloxi Safety Fairway.* The area between lines joining points at:

Latitude	Longitude
30°24' 06"	88°50' 57"
30°23' 15"	88°50' 22"
30°21' 11"	88°47' 36"
30°20' 13"	88°47' 04"
30°15' 06"	88°47' 06"
30°13' 09"	88°47' 46"
30°12' 23"	88°49' 02"

and lines joining points at:

Latitude	Longitude
30°24' 27"	88°50' 31"
30°23' 57"	88°49' 31"
30°21' 42"	88°46' 36"
30°20' 25"	88°45' 55"
30°14' 57"	88°45' 57"
30°12' 56"	88°46' 39"
30°12' 00"	88°45' 25"

(36) *Ship Island Pass to Horn Island Pass Safety Fairway.* The areas between rhumb line joining points at:

Latitude	Longitude
30°05' 42"	88°56' 24"
30°06' 38"	88°31' 26"

and rhumb line joining points at:

Latitude	Longitude
30°07' 42"	88°55' 37"
30°08' 27"	88°36' 57"

(37) *Pascagoula Safety Fairway.* The areas between rhumb lines joining points at:

Latitude	Longitude
30°20' 46"	88°34' 39"
30°20' 21"	88°34' 39"
30°17' 00"	88°31' 21"
30°12' 59"	88°30' 53"
30°11' 50"	88°32' 05"
30°08' 27"	88°36' 57"
30°06' 38"	88°31' 26"
29°56' 43"	88°20' 50"
29°55' 14"	88°19' 15"
29°20' 00"	87°41' 47"

and rhumb line joining points at:

Latitude	Longitude
30°20' 30"	88°33' 18"
30°18' 39"	88°31' 25"

and rhumb line joining points at:

Latitude	Longitude
30°20' 26"	88°31' 25"
30°18' 39"	88°31' 25"

and rhumb lines joining points at:

Coast Guard, DOT

§ 166.200

Latitude	Longitude
30°19' 21"	88°30' 12"
30°17' 25"	88°30' 12"
30°12' 46"	88°29' 42"
30°11' 21"	88°31' 00"
30°09' 33"	88°29' 48"
30°07' 30"	88°29' 09"
29°58' 03"	88°19' 05"
29°56' 34"	88°17' 30"
29°20' 48"	87°39' 31"

(38) *Horn Island Pass to Mobile Ship Channel Safety Fairway.* The areas between rhumb line joining points at:

Latitude	Longitude
30°09' 33"	88°29' 48"
30°07' 15"	88°06' 54"

and rhumb line joining points at:

Latitude	Longitude
30°07' 30"	88°29' 09"
30°05' 29"	88°09' 19"

(39) *Mobile Safety Fairway—(i) Mobile Ship Channel Safety Fairway.* The areas between rhumb lines joining points at:

Latitude	Longitude
30°38'46" N	88°03'24" W
30°38'14" N	88°02'42" W
30°31'59" N	88°02'00" W
30°31'59" N	88°04'59" W

and rhumb lines joining points at:

Latitude	Longitude
30°31'00" N	88°05'30" W
30°31'00" N	88°01'54" W
30°26'55" N	88°01'26" W
30°16'35" N	88°02'45" W
30°14'09" N	88°03'24" W
30°10'36" N	88°03'53" W
30°08'10" N	88°04'40" W
30°07'15" N	88°06'54" W

and rhumb lines joining points at:

Latitude	Longitude
30°39'55" N	88°01'15" W
30°37'06" N	88°01'23" W
30°26'11" N	88°00'11" W
30°16'18" N	88°01'35" W
30°13'52" N	88°01'12" W
30°13'14" N	88°01'12" W
30°10'36" N	88°01'35" W
30°08'04" N	88°00'36" W

(ii) *Mobile Ship Channel to Sea Safety Fairway.* The areas between rhumb lines joining points at:

Latitude	Longitude
30°05' 15"	88°01' 13"
30°03' 50"	88°00' 00"

Latitude	Longitude
29°25' 46"	87°29' 13"

and rhumb line joining points at:

Latitude	Longitude
30°06' 17"	87°59' 15"
29°27' 00"	87°27' 18"

(iii) *Mobile to Pensacola Safety Fairway.* The areas between rhumb line joining points at:

Latitude	Longitude
30°08' 04"	88°00' 36"
30°14' 20"	87°19' 05"

and rhumb line joining points at:

Latitude	Longitude
30°06' 17"	87°59' 15"
30°12' 31"	87°18' 00"

(40) *Mobile Anchorage.* The areas within rhumb lines joining points at:

Latitude	Longitude
30°05' 15"	88°06' 05"
30°05' 15"	88°01' 13"
30°03' 50"	88°00' 00"
30°03' 50"	88°08' 01"

(41) *Pensacola Safety Fairway.* The areas between rhumb lines joining points at:

Latitude	Longitude
30°23' 41"	87°14' 34"
30°23' 06"	87°13' 53"
30°22' 54"	87°13' 53"
30°20' 47"	87°15' 45"

and rhumb lines joining points at:

Latitude	Longitude
30°18' 43"	87°19' 24"
30°15' 57"	87°18' 19"
30°14' 20"	87°19' 05"
30°12' 31"	87°18' 00"
30°10' 03"	87°18' 00"
29°37' 00"	87°18' 00"

and rhumb lines joining points at:

Latitude	Longitude
30°26' 27"	87°08' 28"
30°25' 35"	87°10' 30"

and rhumb lines joining points at:

Latitude	Longitude
30°24' 36"	87°07' 07"
30°22' 57"	87°09' 38"
30°22' 36"	87°11' 50"
30°19' 21"	87°14' 46"
30°19' 52"	87°17' 31"

§ 166.200

and rhumb lines joining points at:

Latitude	Longitude
30°19' 15"	87°17' 37"
30°16' 28"	87°16' 32"
30°14' 32"	87°16' 06"
30°12' 33"	87°15' 43"
29°42' 30"	87°15' 43"

(42) *Pensacola Anchorage.* (i) The area within rhumb lines joining points at:

Latitude	Longitude
30°11' 49"	87°22' 41"
30°12' 31"	87°18' 00"
30°10' 03"	87°18' 00"
30°09' 21"	87°22' 41"

(ii) The area within rhumb lines joining points at:

Latitude	Longitude
30°16' 28"	87°16' 32"
30°17' 14"	87°11' 52"
30°15' 14"	87°11' 52"
30°14' 32"	87°16' 06"

(43) *Pensacola to Panama City Safety Fairway.* The area between rhumb lines joining points at:

Latitude	Longitude
30°14' 32"	87°16' 06"
30°15' 14"	87°11' 52"
30°18' 45"	86°50' 00"
30°18' 00"	86°20' 00"
29°51' 30"	85°47' 33"

and rhumb lines joining points at:

Latitude	Longitude
30°12' 33"	87°15' 43"
30°16' 44"	86°49' 49"
30°16' 01"	86°20' 57"
29°48' 45"	85°47' 33"

(44) *Panama City Safety Fairways.* The areas between rhumb lines joining points at:

Latitude	Longitude
30°09'24"	85°40'12"
30°09'21"	85°41'40"
30°07'36"	85°44'20"
30°06'32"	85°47'33"
29°51'30"	85°47'33"
29°48'45"	85°47'33"
29°03'30"	85°47'33"

and rhumb lines joining points at:

Latitude	Longitude
30°08'34"	85°40'16"
30°07'55"	85°41'50"
30°06'49"	85°43'28"
30°04'40"	85°45'15"
29°55'27"	85°45'15"
29°51'20"	85°45'15"

33 CFR Ch. I (7-1-99 Edition)

Latitude Longitude

29°49'19"	85°45'15"
29°00'00"	85°45'15"

(45) *Panama City Anchorage.* The area within rhumb lines joining points at:

Latitude	Longitude
29°55' 27"	85°45' 15"
29°55' 27"	85°42' 25"
29°51' 39"	85°42' 25"
29°51' 20"	85°45' 15"

(46) *Port St. Joe Fairway to Panama City Fairway.* The area between rhumb lines joining points at:

Latitude	Longitude
29°49' 54"	85°19' 24"
29°50' 59"	85°22' 25"
29°53' 32"	85°22' 25"
29°54' 12"	85°24' 00"
29°54' 12"	85°25' 55"
29°52' 58"	85°28' 43"
29°53' 00"	85°29' 48"
29°51' 39"	85°42' 25"
29°51' 20"	85°45' 15"

and rhumb lines joining points at:

Latitude	Longitude
29°48' 22"	85°18' 12"
29°47' 21"	85°21' 00"
29°50' 42"	85°23' 31"
29°52' 51"	85°23' 36"
29°53' 10"	85°24' 18"
29°53' 10"	85°25' 33"
29°51' 57"	85°28' 19"
29°51' 04"	85°29' 00"
29°50' 40"	85°32' 39"
29°49' 19"	85°45' 15"

(47) *Port St. Joe Anchorage.* The area within rhumb lines joining points at:

Latitude	Longitude
29°50' 40"	85°32' 39"
29°51' 04"	85°29' 00"
29°49' 18"	85°30' 18"

(48) *Tampa Safety Fairways.* The area between rhumb lines joining points at:

Latitude	Longitude
27°37' 48"	82°45' 54"
27°36' 48"	82°55' 54"
27°36' 48"	83°00' 00"
27°36' 48"	84°39' 10"

and rhumb lines joining points at:

Latitude	Longitude
27°35' 54"	82°45' 42"
27°34' 48"	82°55' 54"
27°34' 48"	83°00' 00"
27°34' 48"	84°39' 00"

Coast Guard, DOT

§ 166.300

(49) Tampa Anchorages—(i) Eastern Tampa Fairway Anchorage. The area enclosed by rhumb lines [North American Datum of 1927 (NAD-27)] joining points at:

Latitude	Longitude
27°36'48"N..	83°00'00"W..
27°39'00"N..	83°00'00"W..
27°39'00"N..	82°55'54"W..
27°36'48"N..	82°55'54"W..

(ii) Western Tampa Fairway Anchorage. The area enclosed by rhumb lines [North American Datum of 1927 (NAD-27)] joining points at:

Latitude	Longitude
27°36'48"N..	83°05'06"W..
27°39'00"N..	83°05'06"W..
27°39'00"N..	83°01'00"W..
27°36'48"N..	83°01'00"W..

(50) *Charlotte Safety Fairways*. The area between rhumb lines joining points at:

Latitude	Longitude
26°41' 18"	82°19' 00"
25°30' 00"	84°22' 00"

and rhumb lines joining points at:

Latitude	Longitude
26°40' 19"	82°18' 28"
26°38' 30"	82°19' 54"
26°39' 00"	82°19' 00"
25°28' 00"	84°21' 30"

(51) *Charlotte Anchorage*. The area within rhumb lines joining points at:

Latitude	Longitude
26°39' 00"	82°19' 00"
26°38' 12"	82°18' 24"
26°37' 36"	82°19' 18"
26°38' 30"	82°19' 54"

(52) *Louisiana Offshore Oil Port (LOOP) Shipping Safety Fairway to Safety Zone*. (i) North of Gulf Safety Fairway. The two mile wide area enclosed by rhumb lines joining points at:

Latitude	Longitude
28°48' 36"	89°55' 00"
28°48' 14"	89°54' 17"
28°45' 47"	89°54' 19"
28°36' 06"	89°55' 44"
28°18' 30"	89°55' 15"
28°20' 58"	89°53' 03"
28°36' 09"	89°53' 28"
28°49' 07"	89°51' 30"
28°50' 20"	89°53' 51"

(ii) South of Gulf Safety Fairway. The two mile wide area enclosed by rhumb lines joining points at:

Latitude	Longitude
28°15' 20"	89°55' 10"
27°46' 29"	89°54' 23"
27°46' 32"	89°52' 08"
28°17' 48"	89°52' 58"

(53) *Heald Bank Cutoff Safety Fairway*. The area enclosed by rhumb lines, [North American Datum of 1927 (NAD-27)], joining points at:

Latitude	Longitude
28°57'15" N	94°23'55" W
28°51'30" N	93°56'30" W
28°48'30" N	93°51'45" W
28°55'15" N	94°23'55" W

[CGD 81-040, 47 FR 20581, May 13, 1982]

EDITORIAL NOTE: For FEDERAL REGISTER citations affecting § 166.200, see the List of CFR Sections Affected in the Finding Aids section of this volume.

§ 166.300 Areas along the coast of California.

(a) *Purpose*. Fairways as described in this section are established to control the erection of structures therein to provide safe vessel routes along the coast of California.

(b) *Designated Areas*—(1) *Port Hueneme Safety Fairway*. An area one nautical mile in width centered on the alignment of Port Hueneme Entrance Channel and extending seaward from the 30-foot-depth curve for a distance of 1.5 nautical miles, thence turning southerly and widening to 1.5 nautical miles at the 3-mile limit, all between lines joining the following points:

Latitude	Longitude
34°06'30" N	119°15'00" W
34°07'37" N	119°14'25" W
34°08'49" N	119°13'21" W

thence generally along the 30-foot-depth curve to the seaward end of the west entrance jetty; seaward end of the east entrance jetty, thence generally along the 30-foot-depth curve to:

Latitude	Longitude
34°08'21" N	119°12'15" W
34°07'10" N	119°13'20" W
34°05'48" N	119°13'23" W

(2) [Reserved]

[CGD 82-101, 48 FR 49019, Oct. 24, 1983]